

EN





In addition to what is explained below, the safety and installation information provided in the installation manual must be read and followed. The technical documentation and the interface and management software for the product are available at the website. The device must be used in the manner described in the manual. If this is not the case the safety devices guaranteed by the inverter might be ineffective.



# 1. Labels and Symbols

The labels on the converter have the Agency marking, main information, identification of the equipment and manufacturer



- 01 Converter Part Number
- 02 Converter model
- 03 Converter Serial Number
- 04 Week/Year of manufacture

The labels attached to the equipment must NOT be removed, damaged, dirtied, hidden, etc... In the manual and/or in some cases on the equipment, the danger or hazard zones are indicated with signs, labels, symbols or icons.


Always refer to instruction manual	General warning - Important safety information	Hazardous voltage	Hot surfaces
Protection rating of equipment	Temperature range	Always use safety clothing and/or personal safety devices	Point of connection for grounding protection

# 2. Converter Models and Components

The model of converter to which this guide refers is PVI-USB-RS232\_485.

## Main components


- 01 PVI-USB-RS232\_485 converter
- 02 Reset button
- 03 "TX/RX" Led
- 04 "PWR OK" Led
- 05 USB port Type B (laterally)
- 06 Switch for the RS232 or RS485 serial line setting
- 07 Serial line connector



# 3. Rules for the creation of the RS485 communication line


- Connect all the units to the RS485 chain according to the "daisy-chain" scheme observing the correspondence between signals (refer to inverter product manual)
- In the last unit of the chain, activate the ending resistance of the communication line through the switching of the dip-switch dedicated
- Set on each inverter of the chain an RS485 exclusive address (a different address for each inverter)
- The communication line must not exceed 1000m length

In case of communication lines are especially long, it is advisable to/ it could be necessary the use of signal amplifier which has to be installed along the communication line



**Characteristics of application cables for the creation of the RS485 communication line**  
The cable which must be used to create the serial communication line RS485 must have the following characteristics:

Section	Max. Length	Characteristic impedance	Specific capacity
Min. AWG24 / 0.25mm <sup>2</sup>	1000mt	120Ω	Included between 50 and 100pF/mt




# 4. Connection to the RS485 line

Inside the inverters the connection to the RS485 line can be made indifferently through the couple of connector RJ12/RJ45 (one for the input and one for the output of the RS485 line) or through the terminal block.


- In case of terminal block it must be used RTN(or GND COM), +T/R (or D+) and -T/R(or D-) terminals.
- In case of RJ12/RJ45 connector the plugs you have to use must be wired according to the scheme in following table:

## Crimping scheme of RJ12 connectors



Pin N°	Function
2	+T/R or D+
4	-T/R or D-
6	RTN or GND COM
1, 3, 5	not used

## Crimping scheme of RJ45 connectors





Pin N°	Function
3	+T/R or D+
5	-T/R or D-
7	RTN or GND COM
1, 2, 4, 6, 8	not used


The connection of the RS485 serial line to the converter PVI-USB-RS232\_485 is made on the terminal board with 4 poles:

- To the terminal D- must be connected the terminal -T/R or D- coming from the inverter
- To the terminal D+ must be connected the terminal +T/R or D+ coming from the inverter

D+ > +T/R  
D- > -T/R  
RTN




# 5. Connection to the PC




Insert the USB cable into the converter and in the PC

## Installation procedure of the USB driver for the PVI-USB-RS232\_RS485 converter:


In succession is illustrated the procedure of driver installation ver. 2.08.24 issued on the provider website the 26/04/2012. For the last version of the driver and for the compatibility with the most common operating systems, we refer to the table at the end of the procedure.




1. Launch the file CDM20824.exe



2. Click on "Yes"



3. Wait for the complete installation of the drivers




4. Connect the converter to an USB port of the PC. To verify which COM port has been assigned to the converter:

### Path for OS Windows XP

Control panel ► System ► Hardware ► Peripheral management ► Port (COM e LPT).

### Path for OS Windows 7

Control panel ► System ► Device management ► Port (COM e LPT).




5. Making a double click on the USB port, the screen of the port properties turns on. Check on the tab "Driver" that the driver provider is FTDI and the driver version is 2.8.24.0 of the 10/04/2012.


# 8. Commissioning

After connecting and laying the serial line RS485, the procedure of commissioning of the converter is the following:

- Connect the connector coming from the RS485 serial line linked to the inverters and/or stringcomb.



- Connect the USB cable to the PC and check that the green led PWR OK is on.



- Open the interface software ABB and perform the desired operations.

# 6. LEDs and switches

## Table of compatible drivers Ver. 2.8.24.0

Operative S	Device	Driver Ver.	Date
Windows Server 2008 R2			
Windows 7	FT2232H		
Windows 7 x64	FT4232H		
Windows Server 2008	<b>FT232R</b>		
Windows Server 2008 x64	FT245R		
Windows Vista	FT2232	2.8.24.0	10 <sup>th</sup> April 2012
Windows Vista x64	FT232B		
Windows XP	FT245B		
Windows XP x64	FT8U232AM		
Windows 2000	FT8U245AM		
Windows Server 2003			
Windows Server 2003 x64			

The PVI-USB-RS485\_232 finds his functioning on the FTDI FT232R device.

# 6. LEDs and switches

## LED Description



On the converter there are 2 LEDs:

- TX/RX : shows if the converter is communicating or not
- PWR OK : shows if the converter in supplied or not


## RS232/485 Sel. Switch




The "RS232/485 Sel." Switch allows to set the type of input signal (RS232 o RS485).

ABB inverters use the RS485 as serial communication line

"RS232/485 Sel." Switch set in RS485 or RS232 communication line



RS485



RS232

## Reset button




"Reset" button allows to restart the communication with the inverters in case of interruption

# 7. LED Behaviour

The following table shows all the possible combinations of activation of LED relating to the operation status of the converter.

LED status	Operation status
PWR OK:	Converter not supplied or disconnected
TX/RX:	
PWR OK:	Converter supplied. Communication absent
TX/RX:	
PWR OK:	Converter supplied. Communication present
TX/RX:	



# 9. Characteristics and technical data

## PVI-USB-RS232\_485

USB Section	
Standard	2.0
Connection	B-Type
RS485/232 Section	
RS485/232 Interface	can be selected by switch
RS485	Half-Duplex
Status Led (Tx/Rx)	Yes
O.S.	Windows Xp, Windows 7, Linux and derived <sup>(1)</sup>
Power Supply	
Auto power supply	by USB
Maximum Current Absorbed	150 mA
Status Led(Power On)	Yes
Environmental	
Room temperature	-25...+ 50°C / -13...122°F
Physical	
Level of environmental protection	IP 20 (Only for inside use)
Overall dimensions (H x L x P)	66mm x 66mm x 28mm
Security	
Insulation	2500 Vdc
Certification	CE
Attachments	
Connection cable B-type/A-type	Included

1. For a complete list visit: <http://www.ftdichip.com/Drivers/VCP.htm>

**Remark. Features not specifically listed in the present data sheet are not included in the product**

## Contact us

PVI-USB-RS232\_485-Quick Installation Guide EN-RevA

EFFECTIVE 2014-04-30

[www.abb.com/solarinverters](http://www.abb.com/solarinverters)

© Copyright 2014 ABB. All Rights Reserved.  
Specifications subject to change without notice.